


AutoFlood II™



- | | |
|-----------------------------------|---|
| 1. DOOR SPREADER GUSSET | 43. END TOP CHORD/END SHEET |
| 2. DOOR OPERATING LEVER-SHORT | 44. CORNER POST |
| 3. DOOR HINGE | 45. HANDBRAKE MOUNTING PLATE |
| 4. OPERATING BEAM | 46. END POST |
| 5. TRI-LEVER | 47. BRAKE STEP |
| 6. DOOR ASSEMBLY | 48. ROTARY COUPLER YOKE |
| 7. LEVER LINK C | 49. FOLLOWER BLOCK |
| 8. DOOR OPERATING LEVER - LONG | 50. RETAINING KEYS |
| 9. OPERATING BEAM GUIDE | 51. ROTARY END COUPLER |
| 10. VERTICAL DOOR OPERATING LEVER | 52. FIXED END COUPLER |
| 11. LEVER FULCRUM | 53. FOLLOWER BLOCK |
| 12. MAIN OPERATING LINK | 54. DRAFT GEAR |
| 13. ACTUATOR LEVER | 55. FIXED COUPLER YOKE |
| 14. AIRBRAKE CONTROL VALVE | 56. COUPLER PIN |
| 15. LOWER FLOOR SHEET | 57. COUPLER PIN SUPPORT |
| 16. END LONGITUDINAL HOOD | 58. BRAKE DEAD LEVER |
| 17. CROSSRIDGE FLOOR | 59. TRUCK SIDE BEARING |
| 18. CROSSRIDGE BEAM | 60. TRUCK BOLSTER |
| 19. HOPPER DOOR | 61. TRUCK CENTER PIN OR KING PIN |
| 20. HANDBRAKE | 62. BOLSTER BOWL LINER |
| 21. BOLSTER TRANSITION STAKE | 63. BRAKE LIVE LEVER |
| 22. DOOR OPERATING CYLINDER | 64. SIDE FRAME |
| 23. BRAKE RESERVOIR | 65. TRUCK SPRINGS |
| 24. VERTICAL BRAKE LEVER | 66. FRICTION SHOE CASTING |
| 25. END COCK | 67. BRAKE SHOE KEY |
| 26. SILL STEP | 68. COLUMN WEAR PLATE |
| 27. SUB SIDE SILL | 69. BRAKE SHOE |
| 28. END HANDHOLD | 70. BOTTOM ROD OR TRUCK LEVER CONNECTOR |
| 29. SIDE HANDHOLD | 71. ROLLER BEARING |
| 30. BOLSTER WEB | 72. ROLLER BEARING ADAPTER |
| 31. BOTTOM SIDE SILL | 73. AXLE |
| 32. END FLOOR | 74. BRAKE BEAM |
| 33. END SIDE SHEET | 75. WHEEL |
| 34. CENTER SIDE SHEET | 76. PEDESTAL WEAR PLATE |
| 35. WEAR BAR | 77. END OUTSIDE HOPPER SHEET |
| 36. SIDE TOP CHORD | 78. CENTER OUTSIDE HOPPER SHEET |
| 37. TRANSVERSE TIE | 79. INSIDE END HOPPER SHEET |
| 38. DIAGONAL BRACE | 80. INSIDE CENTER HOPPER SHEET |
| 39. CROSSRIDGE SIDE STAKE | 81. HOPPER SHEET STIFFENER |
| 40. INTERMEDIATE SIDE STAKE | 82. DOOR CONTROL VALVE |
| 41. CENTER LONGITUDINAL HOOD | 83. DOOR AIR RESERVOIR |
| 42. CORNER CAP | 84. END SILL |
| | 85. BOLSTER SHEAR PLATE |

**Johnstown
America
Corporation**

17 Johns Street, Johnstown, Pennsylvania 15901 800 458-2235
www.johnstownamerica.com